


















			M3	M4	M5	M6	M8	M10	M12	M14	
Aparatos de colocación manuales	RIVKLE® BRK 01		■	■	■	■					51
	RIVKLE® M2007				■*	■*	■*	■*	■*		51
	RIVKLE® BRK 10				■	■	■	■			52
	RIVKLE® ES 51					■	■	■	■	■	52
	RIVKLE® OPTEX				■	■	■				52
Máquinas de colocación oleoneumáticas	RIVKLE® P2005		■	■	■	■	■	■	■		54
	RIVKLE® P1007		■	■	■	■					54
	RIVKLE® P2007			■	■	■	■	■			55
	RIVKLE® B2007		■	■	■	■	■	■			55
	RIVKLE® P3007						■	■	■	■	56
	RIVKLE® P2007 PN			■**	■**	■**	■**				56
	RIVKLE® P3007 PN						■**	■**			56
	RIVKLE® EPX009		■	■	■	■	■	■	■	■	57
Equipos especiales semiautomáticos	RIVKLE® EPK C			■	■	■	■	■			61
	RIVKLE® EPK HP						■	■	■	■	61
Equipos especiales automáticos	RIVKLE® HSA 2.0			■	■	■	■	■			61
	RIVKLE® ESA 2.0				■	■	■				61

* RIVKLE® PN

**RIVKLE® & RIVKLE® PN

RIVKLE® – Aparatos de colocación manuales

RIVKLE® BRK 01 - Pinza de mano

	Ø RIVKLE®							
	M3	M4	M5	M6	M8	M10	M12	M14
Acero	■	■	■	■				
Acero inoxidable	■	■	■					
Aluminio	■	■	■	■				



Útiles incluidos (M3 - M6)

600 g

235 119 00000

Cofre RIVKLE® BRK 01

Código	Cantidad	RIVKLE® Plus ^{24H}											
		M3	M4	M5	M6	M8	M10	M4	M5	M6	M8	M10	
235 119 00501	x1	x50	x50	x50	x50								
235 119 00502	x1							x50	x50	x50			

RIVKLE® M2007 - Pinza de mano

	Ø RIVKLE®							
	M3	M4	M5	M6	M8	M10	M12	M14
Acero			■	■	■	■	■	
Acero inoxidable			■	■	■	■	■	
Aluminio			■	■	■	■	■	



Útiles incluidos (M5 - M12)

1200 g

235 302 01000

Cofre RIVKLE® M2007

Código	Cantidad	RIVKLE® Plus ^{24H}											
		M5	M6	M8	M10	M12	M6	M8	M10	M6	M8	M10	
235 302 01000	x1	x1	x1	x1	x1	x1							
235 302 01001	x1		x1	x1	x1					x50	x25	x25	
235 302 01002	x1		x1	x1	x1		x50	x25	x25				
		UNC			UNF								
		10-24	1/4-20	5/16-18	10-32	1/4-28	5/16-24						
235 302 01003	x1	x1	x1	x1	x1	x1	x1						

RIVKLE® BRK 10 - Pinza de palanca

	Ø RIVKLE®							
	M3	M4	M5	M6	M8	M10	M12	M14
Acero			■	■	■	■		
Acero inoxidable			■	■	■			
Aluminio			■	■	■	■		

Útiles incluidos (M5 - M10)

 1900 g

 235 120 00 000



RIVKLE® ES 51 - Aparato manual hidráulico

	Ø RIVKLE®							
	M3	M4	M5	M6	M8	M10	M12	M14
Acero				■	■	■	■	■
Acero inoxidable				■	■	■	■	■
Aluminio				■	■	■	■	■



Útiles no incluidos

 2700 g

 235 118 00 000



RIVKLE® OPTEX - Aparato para punzonado hexagonal

			Ø RIVKLE®		
			M5	M6	M8
Acero	0,5 - 2,5 mm		■	■	■
Aluminio			■	■	■




Útiles incluidos (M5 - M8)




 2100 g





 235 110 00 000














Útiles

RIVKLE® BRK 01				Ø RIVKLE®			
				M3	M4	M5	M6
	Vástago + boquilla		235 119 XX 001	03	04	05	06
				↑	↑	↑	↑

RIVKLE® BRK 10				Ø RIVKLE®			
				M5	M6	M8	M10
	Vástago + boquilla		235 120 XX 001	05	06	08	10
				↑	↑	↑	↑

RIVKLE® M2007				Ø RIVKLE®				
				M5	M6	M8	M10	M12
	Vástago		235 302 XX 020	05	06	08	10	12
	Boquilla			235 302 XX 030	05	06	08	10
			↑					

RIVKLE® ES 51				Ø RIVKLE®				
				M6	M8	M10	M12	M14
	Vástago		235 108 XX 020	06	08	10	12	14
	Boquilla			235 108 XX 030	06	08	10	12
			↑					

RIVKLE® OPTEX				Ø RIVKLE®					
				M5	M6	M8			
	Vástago		235 110 XX 020	05	06	08			
	Tuerca			235 110 67 006	✓	✓	✓		
	Boquilla				235 110 XX 030	05	06	08	
	Punzón					235 110 XX 021	05	06	08
	Matriz						235 110 XX 031	05	06
			↑						

